

Code	Description	
FLCS/015	15mm Flamco Connection Set 27290 For vessels 35-300 litres	S
FLCS//025	25mm Flamco Connection Set 27293 For vessels 110-1000 litres	
FLAV/015	15mm Flamco Air Vent Flexvent 27740	
FLF/015 FLF/020 FLF/025 FLF/032	15mm Flamco Funnel 27350 20mm Flamco Funnel 27360 25mm Flamco Funnel 27325 32mm Flamco Funnel 27330	
FLAS/020 FLAS/025 FLAS/032 FLAS/040	20mm Flamcovent Air Seperator 28020 25mm Flamcovent Air Seperator 28021 32mm Flamcovent Air Seperator 28022 40mm Flamcovent Air Seperator 28023	
FLSV015/27665 FLSV020/27025 FLSV025/27045 FLSV032/27056 FLSV27049 FLSV27039	3 Bar Flamco Prescor Safety Valve 15mm 3 Bar Flamco Prescor Safety Valve 20mm 3 Bar Flamco Prescor Safety Valve 25mm 3 Bar Flamco Prescor Safety Valve 32mm 5 Bar Flamco Prescor Safety Valve 25mm 5 Bar Flamco Prescor Safety Valve 32mm	
FLWM27913	Flamco Flexcon MB2 Wall Mounting Clip 27913 For vessels 2-25 litres	



FLWM27910 Flamco Flexconsole 8-25 Wall Mounting 27910

For vessels 8-25 litres



Code Description

FLWM27996 Flamco Flexconsole Plus 8-25 Wall Mounting

For vessels 8-25 litres



Flamco Expsn Vessels Charge Press 1.5 Bar

FLEV8/16077 Flamco C8 Expsn Vessel 16077 max 3 Bar FLEV12/16127 Flamco C12 Expsn Vessel 16127 max 3 bar FLEV18/16177 Flamco C18 Expsn Vessel 16177 max 3 Bar FLEV25/16247 Flamco C25 Expsn Vessel 16247 max 3 bar



FLEV35/16347 Flamco C35 Expsn Vessel 16347 max 3 bar FLEV50/16493 Flamco C50 Expsn Vessel 16493 max 3 bar Flamco C50 Expsn Ves

FLEV80/16817 Flamco C80 Expsn Vessel 16817 max 3 bar



Flamco Expsn Vessels Charge Press 2 Bar

FLEV110/16110 Flamco 110 Expsn Vessel 16110 max 6 bar FLEV140/16141 Flamco 140 Expsn Vessel 16141 max 6 bar FLEV200/16208 Flamco 200 Expsn Vessel 16208 max 6 bar FlEV425/16424 Flamco 300 Expsn Vessel 16304 max 6 bar FlEV600/16604 Flamco 600 Expsn Vessel 16604 max 6 bar Flamco 800 Expsn Vessel 16804 max 6 bar Flamco 800 Expsn Vessel 16804 max 6 bar



FLSP27925 Flamco Disassembly Spanner DT 27925



Frese Auto Balancing Valves



miller
20mm
25mm

Frese Alpha Automatic Balancing Valve With 2 x 1" P/T Plugs, F/F Threads Screwed BSP Parallel Brass DR Body

25Lmm 32mm 40mm


40mm 50mm



Code: FVA

15mm Frese Alpha Automatic Balancing Valve
20mm With 2 x 1" P/T Plugs
25mm Fixed end Female & Female Union
25Lmm With BSP Parallel Threads
32mm Brass DR Body
40mm Complete with Ball Valve & Handle

Automatic Balancing Valve Body With Ball Valve



Code: FVAB

50mm W 65mm 80mm 100mm

Frese Alpha Automatic Balancing Valve With 2 x 2" P/T Plugs

Wafer Type Body Cast Steel





Code: FVA

Type 10 Type 11 Type 12 Type 30 Frese High Pressure Alpha Cartridge Tin / Nickel Plated Brass DR Alpha Cartridge



Type 40 Code: FC49

Type 10 Type 11 Type 12

Type 30

Frese Oriface Plate Tin / Nickel Plated Brass DR Alpha Orifice



Type 40 Code: FO49

10





VALVES & ACCESSORIES














STROMAX 4115 INCLINED VALVE	CODE
15mm Stromax Valve	HVS/141150
20mm Stromax Valve	HVS/1411502
25mm Stromax Valve	HVS/1411503
32mm Stromax Valve	HVS/1411504
50mm Stromax Valve	HVS/1411506
80mm Stromax Valve	HVS/1411508

 STROMAX-M 4117 CIRCUIT REG V/V WITH MEASURING V/V

 15mm Stromax Valve
 HVS/1411751

 20mm Stromax Valve
 HVS/1411752

 25mm Stromax Valve
 HVS/1411753

STROMAX 4217 GM CIRCUIT REGV/V WITH MEASURING V/V 15mm Stromax Valve HVS/1421711 20mm Stromax Valve HVS/1421712 25mm Stromax Valve HVS/1421713 32mm Stromax Valve HVS/1421714 40mm Stromax Valve HVS/1421715 50mm Stromax Valve HVS/1421716 65mm Stromax Valve HVS/1421717 80mm Stromax Valve HVS/1421718

STROMAX GF FLGD CIRCUIT V/V WITH MEASURING V/V
50mm Stromax GF Valve HVS/1421870GF
65mm Stromax GF Valve HVS/1421871GF
60mm Stromax GF Valve HVS/1421873GF
100mm Stromax GF Valve HVS/1421873GF
Sizes 125mm to 300mm available on indent

STROMAX-GMF & MFS CIRCUIT V/V WITH MEASURING V/V
50mm Stromax GMF Valve HVS/ 1421846
65mm Stromax GMF Valve HVS/ 1421847
80mm Stromax GMF Valve HVS/ 1421848
100mm Stromax MFS Valve HVS/ 1421809

 DR-T-90 RADIATOR CONTROL VALVE - STRAIGHT MODEL

 15mm DR-T-90 STR
 HVR/1682391

 20mm DR-T-90 STR
 HVR/1682392

 25mm DR-T-90 STR
 HVR/1682373

 DR-T-90 RADIATOR CONTROL VALVE - ANGLE MODEL

 15mm DR-T-90 STR/LS
 HVR/1682491

 20mm DR-T-90 STR/LS
 HVR/1682492

 25mm DR-T-90 STR/LS
 HVR/1682473

FOR INFORMATION AND ORDERS CALL 09-573 0099 CALL FREE 0800-ASMUSS FAX 09-573 5590





DR-T-90 RADIATOR CONTROL VALVE - LOCKSHIELD
STRAIGHT MODEL

15mm DR-T-90 STR/LS

20mm DR-T-90 STR/LS

HVR/1682382
25mm DR-T-90 STR/LS

DR-T-90 RADIATOR CONTROL VALVE - LOCKSHIELD
ANGLE MODEL

15mm DR-T-90 Ang/LS

HVR/1682481

TS-90 THERMOSTATIC VALVE - STRAIGHT MODEL

15mm TS-90 STR HVR/1772391

20mm TS-90 STR HVR/1772392

20mm DR-T-90 Ang/LS

25mm DR-T-90 Ang/LS

TS-90 THERMOSTATIC VALVE - ANGLE MODEL

15mm TS-90 Ang HVR/1772491

20mm TS-90 Ang HVR/1772492

TS-90 THERMOSTATIC VALVE - REVERSE ANGLE MODEL
15mm TS-90 Rev Ang HVR/1772891

THERMOSTATIC HEAD

Thermostatic Head HVT/1723006

Herzcules Anti-Vandal Head HVT/1986010

HVR/1682482

HVR/1682486

THERMOSTAT WITH REMOTE ADJUSTMENT
Thermostat Remote HVT/1733005

THERMOSTAT WITH REMOTE SENSOR
Thermostat Remote HVT/7450

 FILL AND DRAIN COCK

 15mm Drain Cock Itap 139
 HVD/1411901

 20mm Drain Cock Herz 4119
 HVD/1400902

FOR INFORMATION AND ORDERS CALL 09-573 0099 CALL FREE 0800-ASMUSS FAX 09-573 5590



VALVES & ACCESS	ORIES	
	HOSE CONNECTION 15mm Hose Conn	CODE HVH/1620601
	CONNECTION ELBOW 15mm Conn Elbow	HVE/1624901
	PRESETTING KEY Yellow Shaft Blue Shaft	HVK/1680000 HVK/1660000
	ASSEMBLY KEY Assembly Key	HVK/1668000
₩ v	THEFT PROTECTION Theft Protection	HVP/1755203
	O RING SET O-Ring Set	HVO/1671000
	MEASURING VALVE FOR STROMAX-M 1/4" Measuring Valve	HVV/1028009
	THERMOSTATIC UPPER PART Thermostatic Adaptor	HVT/1637600
	HANDWHEEL FOR HERZ-DR-T-0-90 Handwheel	HVH/1651090
	LOCKSHIELD FOR HERZ-DR-T-90 Lockshield	HVL/1651290
	BINDER TEST POINTS 8mm Red 8mm Blue	HVTPR/008 HVTPB/008
6	AIR RELEASE VALVE Itap Fig 194	HVAR/008

FOR INFORMATION AND ORDERS CALL 09-573 0099 CALL FREE 0800-ASMUSS FAX 09-573 5590